Fischer 1605U-45 6-5/8" Solid Brass Nautical Quartz Clock, Arabic User Manual

Table of Contents

1. Introduction 2
2. Care and Cleaning 2
3. Battery and Installation 2
4. Setting the Time 3
5. Warranty Information 3
6. Liability Disclaimer 3

©Copyright 2013, Ambient LLC. All Rights Reserved.

1. Introduction

Thank you for your purchase of the Fischer 1605U-45 6-5/8" Solid Brass Nautical Quartz Clock, Arabic. The following is a guide for preparation, care and operation of your marine weather instrument.

Note: Some of the images are generic and may not match your exact model.

2. Care and Cleaning

Avoid use of harsh household cleaners and coarse paper towels, which can scratch the bezel or lens. Fingerprints and dirt may be removed the lenses and bezels with a soft cloth lightly dampened with a mixture of water and mild dishwashing liquid. Be sure to dry the lens and bezel with a soft cloth after cleaning.

3. Battery and Installation

To open or close the clock housing, turn the bayonet lock, as shown in Figure 1. Do not over tighten when closing.

Figure 1

1. Open the housing to expose the time mechanism and insert one AA battery, as shown in Figure 2.

 ©Copyright 2013, Ambient LLC. All Rights Reserved.



Figure 2

2. Fix the clock to a wall with a wall mounting hook or nail.

4. Setting the Time

To set the time, turn the adjustment wheel in the clockwise direction, as shown in Figure 2.

5. Warranty Information

Ambient, LLC provides a 5-year limited warranty on this product against manufacturing defects in materials and workmanship.

This limited warranty begins on the original date of purchase, is valid only on products purchased and only to the original purchaser of this product. To receive warranty service, the purchaser must contact Ambient, LLC for problem determination and service procedures.

Warranty service can only be performed by a Ambient, LLC. The original dated bill of sale must be presented upon request as proof of purchase to Ambient, LLC.

Your Ambient, LLC warranty covers all defects in material and workmanship with the following specified exceptions: (1) damage caused by accident, unreasonable use or neglect (lack of reasonable and necessary maintenance); (2) damage resulting from failure to follow instructions contained in your owner's manual; (3) damage resulting from the performance of repairs or alterations by someone other than an authorized Ambient, LLC authorized service center; (4) units used for other than home use (5) applications and uses that this product was not intended, such as outdoor use.

This warranty covers only actual defects within the product itself, and does not cover the cost of installation or removal from a fixed installation, normal set-up or adjustments, claims based on misrepresentation by the seller or performance variations resulting from installation-related circumstances.

6. Liability Disclaimer

Reading the "User manual" is highly recommended. The manufacturer and supplier cannot accept any

 ©Copyright 2013, Ambient LLC. All Rights Reserved.

responsibility for any incorrect readings and any consequences that occur should an inaccurate reading take place.

The specifications of this product may change without prior notice.

This product is not a toy. Keep out of the reach of children.

No part of this manual may be reproduced without written authorization of the manufacturer.

Ambient, LLC WILL NOT ASSUME LIABILITY FOR INCIDENTAL, CONSEQUENTIAL, PUNITIVE, OR OTHER SIMILAR DAMAGES ASSOCIATED WITH THE OPERATION OR MALFUNCTION OF THIS PRODUCT.

 ©Copyright 2013, Ambient LLC. All Rights Reserved.